

Upgrading from one to two (or more) Hue Bridges

Due to getting more and more lights, I decided to add an extra Hue Bridge - rumours said that around 50 lights, the Hue Bridge could be slow...

So in the Office now:



So I learned a few important lessons here:

✓ A Hue light can be in zero or one room, but in many zones.

✓ Each Hue light must have a Room to be "persisted" as belonging to a Bridge. Otherwise it will be found on each scan by other Bridges.

The last one gave me some hurdles, as many of my outside lights and a few inside lights was only in zones, so when I started to scan the new (second) Bridge, it did find some lights that should be on the first Bridge; and as You can select lights after a scan, this gave some extra work moving them back to the first Bridge.

But thinking of the 2 lessons above, to move a single light from one Bridge to another:

- Remove the light from all zones
- Remove the light from the room it belongs to.
- Switch the Hue App to the second bridge and do a scan.
- It should find the light that was deleted from the other bridge.
- Make sure the light belongs to a room.

As for me, the outside can be solved in 2 ways:

- Create a room called "Outside" with all lights, and zones for the grouping of lights
- Or create rooms for the grouping of lights, and You normally would indoors.